



All tube-ends are labeled with a number sticker. Tube-ends should be connected 1 to 1, 2 to 2, 3 to 3, etc.

1. Connect upright sections together.
2. Slide corner bracket over upright until push button clicks into place.
3. Slide upright over base upright until push button clicks into place.
4. Press bottom crossbar sections in between uprights until push buttons click into place.
5. Press top crossbar sections in between uprights until push buttons click into place.
6. Slide pillowcase graphic over frame and zipper at bottom to complete unit assembly (not shown).

NOTE: Model shown below may differ from your model. While the number of crossbar and upright sections may differ depending on the model, assembly instructions remain the same.

